



VOLA 1611, 1621, 1641T8  
VOLA 1671, 1671-HT2

Fitting instruction  
Montageanleitung  
Monteringsvejledning  
Monteringsvægledning  
Montage hanleiding  
Manuel de montage




| Data                                                                                               | Bar:    | 1    | 2    | 3    | 4    | 5    |
|----------------------------------------------------------------------------------------------------|---------|------|------|------|------|------|
| 1611/1621                                                                                          | l/min   | 13.4 | 18.9 | 23.2 | 26.8 | 30.0 |
|                                                                                                    | Gal/min | 3.5  | 5.0  | 6.1  | 7.1  | 7.9  |
| 1641                                                                                               | l/min   | 11.4 | 16.2 | 19.8 | 22.9 | 25.6 |
|                                                                                                    | Gal/min | 3.0  | 4.3  | 5.3  | 6.1  | 6.8  |
| 1641 - T2                                                                                          | l/min   | 6.6  | 9.4  | 11.5 | 13.3 | 14.8 |
|                                                                                                    | Gal/min | 1.74 | 2.5  | 3.0  | 3.5  | 3.9  |
| 1671 - T2<br>1671-HT2                                                                              | l/min   | 9.9  | 14.0 | 17.2 | 19.9 | 22.2 |
|                                                                                                    | Gal/min | 2.6  | 3.7  | 4.5  | 5.3  | 5.9  |
|  Max. 65°C. 150°F |         |      |      |      |      |      |


1611: A    1621: B








1641T8:







1671:



1671-HT2:







# VOLA T2




VOLA A/S • Lunavej 2 • DK-8700 Horsens • Tel. +45 70 23 55 00  
Fax +45 70 23 55 11 • [sales@vola.dk](mailto:sales@vola.dk) • [www.vola.com](http://www.vola.com)

vola®


VOLA T2




T4




T5




T6




T7




T11




T16




T14




T8




T9




T3



T27



VOLA T3, T4, T5, T6, T7, T8, T9, T11, T14, T16, T27




vola


www.vola.com

mnt\_T3-T27\_V3\_40999247  
01-04-2022


T4, T5, T6, T7, T11, T16, T27




T8, T9, T14



T3





VR040D/: VR22, VR44, VR45, VR246, VR249, VR623, VR624/A/C/D/E/F, 2xVR631, VR1902  
 VR1640: VR23, VR44, VR45, VR47, VR246, VR249, VR623, VR624/A/C/D/E/F, 2xVR631, VR1902



**vola**  
 Lunavej 2  
 DK-8700 Horsens  
 Tlf : + 45 7023 5500  
 sales@vola.com  
 www.vola.com


**VOLA 1641T8**

Date  
 Jan. 96


Rev.  
 2

Sheet  
 SB 50A

T2V:



T2:



vola

Lunavej 2  
DK-8700 Horsens  
Tlf : + 45 7023 5500  
sales@vola.com  
www.vola.com



## VOLA T2V & T2

Date  
Sep. 07

Rev.  
1

Sheet  
SB 40





**VOLA A/S**  
 Lunavej 2  
 DK-8700 Horsens  
 Tlf : + 45 7023 5500  
 Fax: + 45 7023 5511  
 sales@vola.com  
 www.vola.com

**VOLA T8**

Dato

Jan. 96

Rev.

1

Blad

SB 40.6